

3600 Lumen Base Removal Instructions



Step One: Remove bulb from packaging. Lay on a clean surface.



Step Two: With a screwdriver gently unscrew from the base (screw is magnetic).



Step Three: Pull out the screw and lift the base off of the bulb.



Step Four: Grab one of the bases supplied in the 3600 kit. Slide the base over the bulb and match up the hole to the base. Then place the screw in the hole and twist the screw in until snug. Success, you have removed and added a new base!