



KTM 1190 LED Headlight Bulb Installation Instructions

Tools Required After Removal Of Headlight: Drill 1/8", Rivet Gun

1. Remove Headlight & factory bulbs. Pay attention as to what wires go to each bulb.
2. Install the Cyclops LED's. The emitters should be pointing left & right after installation.
3. Place Canbus Interface Plate approx. $\frac{3}{4}$ of an inch back from the bulge in the headlight bucket. Alternatively, You can also install the Plates underneath the shell in approximately the same location, **Note:** these do get hot.



4. Drill 1/8" hole through the headlight bucket using one of the holes in the Canbus Adapter Plate, as a guide.
5. Pop rivet the plate to the headlight bucket using the provided rivets & backing washer. Do both sides, alternatively use double back tape for test fitting.
6. Test fit the headlight.
7. If the headlight goes back in with no obstruction, drill & rivet the other mounting hole.
8. Hook Canbus interface wires up to the LED headlight & the bikes headlight wires. Make sure that you know which is high & low.



9. Re-install headlight. Test aim, as it is common to need to re-adjust the headlight after the LED's light install.