



## Polaris AC powered H13 headlight Kit install instructions.

Thank you for purchasing the Cyclops Adventure Sports LED headlight kit.

This kit is a direct plug and play setup for all Polaris snowmobiles using Ac power to the headlights and H13 bulbs.

1. Start by removing the hood from your sled, we recommend sitting it upside down on some type of padding to prevent scratching.
2. Remove the stock headlight bulbs.
3. Install the new Cyclops led headlight bulb in both sockets. Make sure the bulbs have the emitters facing left and right in a angled manner to align with the factory reflector.
4. Clean the area where the cyclops rectifier and driver box will be mounted with alcohol or some other cleaning solution.
5. Per the photo below mount the rectifier and driver box, make sure you have them mounted close enough so you can plug in the bulb.
6. Use zip ties to securely tie the wires up out of the way.
7. It is normal for the lights to flicker slightly at Idle.

