



Determine where you want to mount the tube mounts. Wrap friction tape around the mounting location (make 2 rotations and stretch the tape to ensure it holds). This not only increases the mount's holding power but also protects the paint on your crash bars.

It's important to apply lock tight to the barrel of the mounting platform. Remove the **Base Pivot** and clean any manufacturing residue with alcohol or a degreaser. We recommend using **RED lock tight** at the barrel joint, **NOT ON THE SCREW**. Allow it to dry before riding your bike. You can choose to mount the light on either side of the **Base Pivot**; it's up to you and what fits your light.



Determine where you want to mount the tube mounts. Wrap friction tape around the mounting location (make 2 rotations and stretch the tape to ensure it holds). This not only increases the mount's holding power but also protects the paint on your crash bars.

It's important to apply lock tight to the barrel of the mounting platform. Remove the **Base Pivot** and clean any manufacturing residue with alcohol or a degreaser. We recommend using **RED lock tight** at the barrel joint, **NOT ON THE SCREW**. Allow it to dry before riding your bike. You can choose to mount the light on either side of the **Base Pivot**; it's up to you and what fits your light.



Determine where you want to mount the tube mounts. Wrap friction tape around the mounting location (make 2 rotations and stretch the tape to ensure it holds). This not only increases the mount's holding power but also protects the paint on your crash bars.

It's important to apply lock tight to the barrel of the mounting platform. Remove the **Base Pivot** and clean any manufacturing residue with alcohol or a degreaser. We recommend using **RED lock tight** at the barrel joint, **NOT ON THE SCREW**. Allow it to dry before riding your bike. You can choose to mount the light on either side of the **Base Pivot**; it's up to you and what fits your light.