



Super Tenere Headlight Replacement Kit

Disclaimer: We assume you possess the expertise and relevant tools to work on your machine. We also assume you have the OEM/Stock owner's manual or technical service manual for your machine. If you do not possess the skills, knowledge, or tools necessary to perform the installation of electrical and/or aftermarket parts, please see a qualified service provider.

1. Remove OEM/Stock dust caps and headlight bulbs, set aside
2. Remove the sealing rings from your original caps and
 - a. Install the sealing rings on your new Cyclops Dust Caps.
3. Remove the base of your H7 LED headlight replacement bulb and with a gentle counterclockwise twist, the base will slide off the bulb. (The base is the piece that mounts to your reflector)



4. Install the base of the LED headlight into your reflector and secure with the OEM/Stock clips
 - a. The H7 base is oriented so the tab is in the 6 o'clock position
 - b. Take special care to insure the base sits flat in your reflector
 - c. The design is such that is very easy to move the base out of position as you are reattaching your bail wires
 - d. If the light is out of position due to the base not being aligned properly, the beam pattern will be less than satisfactory
5. Plug your new LED headlight into your OEM/Stock headlight connecter



6. Feed the wires and driver into the headlight housing
 - a. The right-side driver will fit into the right side of the housing
 - b. The left-side driver will fit in the left side of the housing
7. Install the H7 LED bulb headlight into base in your headlight assembly.



8. Then test your headlights
9. Install your new Cyclops Dust Caps as you would your OEM dust caps
10. Check your headlight adjustment and aim as necessary

Thank you for your business and please contact us at 1-800-624-0278 with questions

Cyclops Adventure Sports

