



BMW F800 Cap Threading

Disclaimer: We assume you possess the expertise and relevant tools to work on your machine. We also assume you have the OEM/Stock owner's manual or technical service manual for your machine. If you do not possess the skills, knowledge, or tools necessary to perform the installation of electrical and/or aftermarket parts, please see a qualified service provider.

Installation

1. First unscrew bulb from driver at the barrel connector
2. Push the barrel connector through cap from inside.



3. Now push the H7 (has the 2 flat terminals) through the cap from the outside.



4. Reconnect the barrel connector.

