

**Disclaimer:** We assume you possess the expertise and relevant tools to work on your machine. We also assume you have the OEM/Stock owner's manual or technical service manual for your machine. If you do not possess the skills, knowledge, or tools necessary to perform the installation of electrical and/or aftermarket parts, please see a qualified service provider.

## **Cyclops Rectifier Wiring Codes**

Green = Ground

White = Low Beam

Blue = High Beam

**Posi-Tap & Posi-Lock Connector Instructions:** Remove the end cap and place over wire you wish to tap. With wire threaded into cap, tighten cap into the Posi-Tap body.

