



Kawasaki KXF Relay Wire Harness

Disclaimer: We assume you possess the expertise and relevant tools to work on your machine. We also assume you have the OEM/Stock owner's manual or technical service manual for your machine. If you do not possess the skills, knowledge, or tools necessary to perform the installation of electrical and/or aftermarket parts, please see a qualified service provider.

Installation

1. Start by removing the seat and fuel tank and locating the battery to make the positive and negative connections on the battery.
2. Then locate the 4-pin connector located in the vicinity of the front down tube. In some instances, there will be a connector covering this plug. Simply remove the cover plug and install switched power plug.
3. Run power output wire under the fuel tank to a suitable location for the lighting you are installing.
4. Reinstall the fuel tank and test the light.
5. Reassemble your motorcycle.
 - a. Avoid pinch points around triple clamp, seat, and fuel tank.

