



## Resistor Kit for Multifunction Turn Signals

*Disclaimer: We assume you possess the expertise and relevant tools to work on your machine. We also assume you have the OEM/Stock owner's manual or technical service manual for your machine. If you do not possess the skills, knowledge, or tools necessary to perform the installation of electrical and/or aftermarket parts, please see a qualified service provider.*

### Installation

1. Locate the yellow and black wires coming out of the multifunction turn signals.
  - Front or Rear whichever is easiest.
  - One resistor wire is added to the left turn signal light.
  - One resistor wire is added to the right turn signal light.
2. Using the provided Posi-Taps. Connect one lead on the resistor to the black lead on the turn signal. Connect the other lead on the resistor to the yellow lead on the turn signal.

