




Tuff Light Turn Signals for KLR gen 3

Disclaimer: We assume you possess the expertise and relevant tools to work on your machine. We also assume you have the OEM/Stock owner's manual or technical service manual for your machine. If you do not possess the skills, knowledge, or tools necessary to perform the installation of electrical and/or aftermarket parts, please see a qualified service provider.




Thank you for purchasing the Cyclops Adventure Sports Tuff Light turn signals for the KLR gen 3.

- Start by removing the front side panels and remove the factory turn signals.
- Place the turn signal adapter plates(a) into the factory holes. 2 plates per turn signal.
- Run wires for front turn signals(c) through hole and tighten silver lock nut **DO NOT twist turn signal to tighten. Only turn the silver lock nut!!** onto the turn signal stem sandwiching the 2 adapter plates(a) and side panel. Orientate properly. Do not over tighten.
- Install front jumper 'Y' wire to the positive ACC wire (with the female bullet style connector) using supplied posi-tap.
- The front turn signals are ready to be plugged in.




- Remove factory turn signals. Note wire routing.
- Install turn signal adapter plates(a). 2 per turn signal.
- Run wires for rear turn signals through hole and install and tighten silver lock nut **DO NOT twist turn signal to tighten. Only turn the silver lock nut!!** onto the turn signal stem sandwiching the 2 adapter plates and side panel. Orientate properly. Do not over tighten.
- Route wires as per factory wire route.




- Connect the right signal to the grey factory plug and the left turn signal to the black factory plug.
- Using Posi-Tap. Connect the red wire from turn signals to the blue wire on the bike taillight harness for brake light function.
- Using Posi-Tap. Connect the blue wire from turn signals to the red wire on the bike taillight harness for taillight function if desired.
- Locate factory turn signal flasher relay on right hand side of bike next to front right turn signal connector.
- Remove factory flasher and replace with Cyclops L.E.D. flasher (b)
- **TEST SYSTEM:** Plug in front turn signals and test the system to ensure proper functionality. White running light in front when key is turned on. Taillight/running light (dim red) on rears when key is turned on (if desired) Red brake lights (bright red) in back when brake is applied. Amber turn signals when left/right switch is applied.
- Once the proper function is achieved secure all wires. Replace all panels.

Posi-Tap & Posi-Lock Connectors



Kit contents



a	Turn Signal Adapter Plates	Qty 8	e	Posi-Tap for Brake Light (red wires)	Qty 1
b	Cyclops LED Flasher	Qty 1	f	Posi-Tap for Taillight (blue wires)	Qty 1
c	Front Tuff Light Turn Signals	Qty 2			
d	Rear Tuff Light Turn Signals	Qty 2			